

232L, 232R

235R

235RII, 235FR

Spare parts

Ersatzteile


Pièces détachées

Reserve onderdelen


Repuestos

Reservdelar


A 235FR, 235R, 235RII
 *compl 544 21 64-01



A 232L, 232R
 *compl 502 21 92-08 (1"/25,4mm)




B 235FR, 235R, 235R11



537 29 48-01

B 232L, 232R




537 29 48-01




503 79 56-01

C 235FR, 235R, 235R11




C 232R

*compl 503 72 43-03




D 235FR, 235R, 235RII
*compl 537 18 35-07




compl 544 25 10-01


- 503 21 66-18
- 544 25 14-01
- 544 25 08-01




E 232R
 *compl 502 19 58-13




F 232L
 *compl 503 78 05-03




G 232L, 232R







G 235FR, 235R, 235RII




H




J***compl 503 90 47-02****K*****compl 502 18 95-02****L*****compl 503 84 00-02****M**


N *compl 503 79 06-01




P *compl 503 72 80-01 (232L,R) ø35
*compl 503 69 46-01 (235FR,R) ø38
*compl 503 10 41-01 (235RII) ø40




Q *compl 502 21 28-04







- ① 530 03 51-73
Set of gaskets
Dichtungssatz
Jeu de joints
Juego de juntas
Packningssats

S Duo Balance
compl 537 27 57-01
compl 537 27 57-03 US










T Accessories
Zubehöre
Accessoires
Accesorios
Tillbehör



*compl 502 21 60-01 (232)
 **compl 502 21 60-14 (235)






Oil Airfilter
Öl Luftfilter
Aceite Filtro Air
Huile Filtera aire
Olja Luftfilter




(232L, 232R) 503 89 01-01
 (235FR, R, 235RII) 503 89 01-02



(232R) 503 74 40-01



U 235FR, 235R, 235RII
*compl 537 38 77-01



U 235FR, 235R, 235RII
*compl 537 33 16-01

